
SHOPPING LIST	Notes and Ideas
<u> </u>	
Ц	
□	
Π	
□	
□	
□	
Π	
8	





INSTALLING A TILE BACKSPLASH

# WHAT YOU NEED

#### **Materials**

☐ SimpleMat tile setting mat
☐ Premixed grout

Grout sealer

☐ Glass mosaic tile

☐ Tile spacers

2" Scotch Blue multisurface painter's tape

Marker

Fine grit sandpaper

☐ Glass cleaner

☐ Mineral spirits

DAP Aquarium
Adhesive Sealant

#### **Tools**

☐ Grout Float

□ Sponge

☐ Small bucket

☐ Small trowel

Scissors

Latex or nitrile gloves

□ Tape measure

☐ Yardstick

Level

Utility knife

Safety glasses

Step ladder

Small drop cloths

☐ Terry towels

Respirator

☐ Tile Nipper



# **WALL PREPARATION**

Before you start your tiling project, spend some time with some project prep work.


- Use a layer of cardboard or heavy duty craft paper to cover and protect countertops, nearby appliances, and window trim.
- Shut off power to any electrical outlets or light switches and remove the cover plates.
- Remove all existing tiles.
- Clean the drywall. Remove any existing wallpaper, because moisture from the mortar and grout can loosen the wallpaper adhesive over time, causing the tile to fall off.
- Rough up painted walls if needed. Use 80-grit sandpaper to rough over painted walls to ensure the adhesive is able to affix to the wall properly, being careful not to sand through the paint. Remove any dust and let the surface dry.
- Ensure the surface is level. Small dings and scratches can be covered with mastic. If dings and damage have caused uneven spots, patch as needed since SimpleMat will follow the wall surface.

### **ALWAYS TEST FIRST**

If there is doubt about the suitability of your tile or subsurface, test a small section to ensure a positive bond. Press the mat onto the surface in question and then remove it. If it comes off easily, ensure all contaminations are removed and surfaces are flattened. If after doing this, a bond is not achieved, use an alternative method of installation.

# **TYPES OF TILES**

Take some time to look in books and magazines and save a file of photos with tile you might consider for your home. Remember that tile lasts a long time, so you might shy away from trends if you're not willing to replace the tile when you grow tired of it.



2



# **ADHESIVES**

The two basic types of adhesives used to mount the tiles are mastic and SimpleMat.

#### Mastic

If using mastic, backerboard is the best way to set any tiles that will have direct water contact. Refer to the 1-2-3 books for information on using backerboard. With mastic, timing is important. If left untouched for too long, mastic can skim over, requiring you to scrape the skim off, discard it, and apply a fresh layer. Most mastics must set for 16 to 18 hours before grouting.

#### **SimpleMat**

To save time, use SimpleMat:

- It can be used with any type of ceramic, porcelain, stone, or glass tile 1" x 1" or larger, or mosaic tile with mesh backing and with tile and stone up to 8" x 8" as along as the stone is less than 1/2" in thickness
- Choose SimpleMat for kitchen or bath counters, backsplashes, shower walls and tub surrounds (but not for floors, ceilings, shower floors, or outdoors).
- Simplemat is appropriate for many household surfaces, such as drywall, plywood, backerboard, concrete, painted surfaces, laminates, and existing tile surfaces.



JOIN US on the third Thursday of each month for FREE Do-It-Herself Workshops. Each quarter, one workshop will be "Inspired by Pinterest." April 17, 2014 How to Build a

How to Build a Hanging Garden

May 15, 2014 Herb Tower Container Garden June 19, 2013
How to Build
an Outdoor
Occasional Table

July 17, 2014
Decorative
Painting Styles

## **SIMPLEMAT: SETTING THE TILE**

Setting tiles using SimpleMat is easy! Before installing the back-splash, remove any dust or grease. Use a damp sponge to wipe the walls, counters, and the backs of the tiles or stones. Be sure to allow all surfaces to dry before proceeding. Ensure that you have a flat counter or wall surface; do NOT apply to uneven surfaces.

Use the backsplash area measurement to lay the tiles out on a flat surface, using spacers if necessary. Replicate those measurements on the wall. If the space at the end is less than  $\frac{1}{2}$  of a tile, shift the center line to eliminate small tile cuts, allowing for wide, even tiles at both ends.

- 1. Determine placement and cuts Place SimpleMat in position and mark cuts, if needed. Before peeling and adhering SimpleMat, check for areas that need to have cuts made for outlets and switch plates. Cut SimpleMat with scissors or utility knife. Using a utility knife will save you from having to stop to clean the adhesive off of the scissors.
- 2. Peel the backing paper from the mat. Apply it to the wall and flatten air bubbles and creases.
- 3. Smooth out the SimpleMat. Use a grout float to smooth the mat to avoid creases or air bubbles.
- 4. Remove the clear plastic from SimpleMat.
- 5. Set the Tiles. Clean the back of the tile with a damp sponge and allow to dry. If the tile backs are not clean, they will not affix properly. Lightly set the tile into place using tile spaces, if needed. You can remove and re-affix the tile if it isn't set correctly. Spacers may not be needed, depending on the size of the tiles and the size of the desired grout lines. Press firmly to lock the tiles into place. Use the grout float to press the tiles into place.

















#### **GROUT LINES**

You get to decide how much space to leave between tiles. Here are a few guidelines:

- Quarry tiles: Tiles are customarily spaced // inch apart.
- Large, uniform machinemade tiles: Space the tiles ½ to ½ inch apart.
- Large handcrafted tiles, such as saltillo: Space the tiles ½ to ¾ inch apart so their irregular edges are less noticeable and less problematic when laying the tile.
- Marble and granite
   Butt tiles and fill chamfered edges with unsanded grout.
- Ceramic and porcelain: Space tiles ½ to ¼ inch apart.

# **GROUT APPLICATION**

Once your tiles are applied to SimpleMat, you can grout right away. If mixing your own grout, mix the mortar with a paddle and some water. Make sure you wear safety goggles, a dust mask, and rubber gloves, and then follow these instructions:

- 1. Remove any tile spacers.
- 2. Use the trowel to apply grout to the grout float.
- 3. Hold the grout float at a 45 degree angle.
- 4. Spread the grout completely, pushing it at an angle into each joint.
- **5.** Remove excess grout by sweeping the grout float diagonally across the tiles at a steep angle.

# **GROUT AND TILE CLEANING**

Grout will set in about 5 to 15 minutes and have a putty-like consistency. When the grout cannot be dented by pressing into it with a thumbnail, clean the tiles. Using a damp sponge, wipe the tiles diagonally to clean them, rinsing the sponge frequently. Cure the grout by misting it twice a day for 3 days.

# **SEALING AND FINISHING TILE**

Protect your new backsplash by applying a tile and/ or grout sealer after the grout has fully cured.

If you use a grout that you mix yourself, consider using Grout Shield, a grout additive that mixes with cement-based grout in place of water to provide stain resistance. It can be used indoors or outdoors and contains antimicrobial ingredients. It eliminates the need to seal the grout, and comes with a 20-year warranty.

The steps for sealing and finishing tile are as follows:

- 1. Apply the tile and grout cleaner with a sponge once the grout is dry.
- 2. Wait 48–72 hours after curing grout to apply a penetrating sealer. Scrub the surface with a stiff brush and rinse thoroughly before applying the sealer.
  - A sealer protects your tile and grout from both oil and water-based stains and makes everyday clean up easier. Do NOT let excess sealer dry on glazed tiles.
- **3.** Apply caulk between tiles and walls or other seams if necessary.



# **ADDITIONAL RESOURCES**

The Home Depot provides many sources of information, help, and tips available for your projects.

The homedepot.com Web site has a How-To page with project guides with information on:

- How to Use SimpleMat Tile Setting for Easy Tile Installation
- SimpleMat Tile Setting Mat
- How to Install Tile and Backsplashes with SimpleMat Premixed Solutions

How-To Community This community-based site provides an opportunity for customers to ask questions of Home Depot associates and other do-it-yourselfers. Register at community.homedepot.com.

Home Improvement 1-2-3 and Tiling 1-2-3 Both of these books have a section on tiling and Tiling 1-2-3 includes additional creative tiling projects. These books are for sale in your store.









- project checklists
- how-to videos
- on-line social community
- mobile apps for iPhone, Android and Windows 7 devices (to download apps, go to m.homedepot.com/apps)